

Installation: Adaptor Coupling AC / AR / PAC



1. Loosen the clamp bands and slide the coupling onto the smaller pipe. No lubricant is required.
2. Mark half the width of the sleeve at the end of the pipe to be connected.
3. Slide the second pipe into the coupling up to the mark.
4. Tighten the clamp bands one after the other across the width of the coupling to the recommended torque.
5. After installation, compress the pipe bed under the pipe.



Data Sheet available online at:
fernco.de/en/product/adoptor-couplings



Installation Video on YouTube:
[qrc0.de/bfGinj](https://www.youtube.com/watch?v=qrc0de/bfGinj)