

## Installation: Access Point AP



1. Select a suitable position where you want to attach the Access Point. Do not place it in the base of the pipe or opposite branches, as it will protrude slightly on the inside.
2. Drill a 54 mm hole using a core drill. For cast iron pipes, we recommend slightly cooling and lubricating the core bit with water or cutting spray.
3. Deburr the hole to create a smooth drilling edge. Use a file for cast iron pipes if necessary.
4. Insert the Access Point so that its radius matches that of the pipe.
5. Hold the Access Point in position and tighten the screw (clockwise) using a 6 mm hexagon spanner. It is not necessary to tighten the screw as far as it will go.
6. The installation is complete!



Data Sheet available online at:  
[fernco.de/en/product/access-point](https://fernco.de/en/product/access-point)



Installation Video on YouTube:  
[qrco.de/bfWr8e](https://www.youtube.com/watch?v=qrco.de/bfWr8e)