

Installation: Bushes B



1. Measure the width of the coupling and mark half a coupling width on the pipes that are to be connected
2. Slide the bush over the spigot end of the smaller pipe up to the marking
3. Loosen the clamp bands and slide the coupling over the spigot end of the larger pipe. No lubricant is required.
4. Bring both spigot ends together and slide the coupling over the bush, up to the marking until the edges are overlapping
5. Tighten the clamp bands one after the other across the width of the coupling to the required tightening torque
6. After installation, compress the pipe bed under the pipe



Data Sheet available online at:
fernco.de/en/product/bushes



Installation Video on YouTube:
qrco.de/bfWr9Q