

Installation: Chemical Coupling CC



1. Ensure the pipe ends are free from debris and chamfered to a minimum of 3 mm × 45°.
2. Slide the FEP liner and coupling onto the pipes and butt the pipes together.
3. Mark the positions for the PTFE seals symmetrically, to ensure they are directly underneath the clamp bands.
4. Fit the self adhesive seals onto the pipes, overlapping the tape ends.
5. Slide the FEP liner over the seals and apply hot air evenly to shrink it onto the pipe.
6. Position the coupling centrally over the FEP liner and tighten to the recommended torque.



Data Sheet available online at:
fernco.de/eu/product/chemical-couplings



Installation Video on YouTube:
[qrc0.de/bfWrE2](https://www.youtube.com/watch?v=qrc0.de/bfWrE2)