

Installation: Pipe Seal LM



1. Using a suitable hole saw, core a hole to the specified diameter (see data sheet).
2. Use a deburring tool to remove any burrs from the edges of the hole. Clean the surface.
3. Fold the seal and insert it with the profile side A.
4. Unfold the seal inside the hole and pull it back until the lip is in contact with the inner pipe wall.
5. Lightly sand the plain end of the pipe and coat it with a suitable lubricant (Fernco white).
6. Position the pipe at the desired insertion depth.
7. Make sure that the pipe to be connected does not protrude into the main pipe.
8. If the pipe has to be fixed in the longitudinal direction, a clamp band (available separately) must be fitted in the groove provided for this purpose at the profile end B.